



1. Installing and configuring

Requirements for ensuring a smooth *hyperMILL*[®] installation

Windows 10 and Windows 11

1. Your hard drive should have at least 7 GB of free storage space.
2. Is your operating system and CAD platform supported by *hyperMILL*[®]? Please check this in the [release notes](#) in the **Supported software** section.
3. Log in as a local administrator.
4. Stop the scanning process of your antivirus software.

OPEN MIND also recommends excluding the following directories, file types, processes and services from the virus scan:

Directories	
NC file	Specified by the user
Post processor	Specified by the user
CAD file	Specified by the user
hyperMILL installation	Default path: C:\Programs\OPEN MIND\
General workspace	hyperMILL [®] settings -> Application -> Default paths
Project	hyperMILL [®] settings -> Document -> Directories
Licensing software	C:\Program Files (x86)\CodeMeter
OPEN MIND Roaming	C:\Users\User Name\AppData\Roaming\OPEN MIND
OPEN MIND temp	C:\Users\User Name\AppData\Local\Temp\OPEN MIND
<i>hyperMILL</i> [®] tmp	C:\Users\Public\ Documents\OPEN MIND\tmp\
OM ProgramData	C:\ProgramData\OPEN MIND

File types			
*.3df	*.nc	*.ovz	*.tmpof



File types			
*.comp	*.nclist	*.pcf	*.tool
*.def	*.ncmap	*.pof	*.vis
*.h	*.oma	*.ppcfg	*.vmm
*.hmc	*.omx	*.pprpt	*.vnc
*.hmrep	*.omgcfg	*.settings	
*.hvz	*.origin	*.so	

These file types are trusted as they are generated exclusively by *hyperMILL*®.

Processes		
CodeMeter.exe	GetHS.exe	omCheck_x64.exe
cyrunx64.exe	hmc.exe	omHV.exe
	LicenseManager.exe	omHV64.exe
		omToolDBW32.exe
		omToolDBX64.exe

Services
Service of CodeMeter.exe

Please have your IT set the antivirus software according to these specifications.